

Emerald ICE Index Prompt and Database Programming

June 10, 2004

Index Prompt and Database Programming

Index Prompt	Programming Item
01-	1. Extension
01-(SN:101~164)-	Show Extension:
01-SN-01	Position
01-SN-02	Tenant Group
01-SN-03	Pickup Group
01-SN-04	Paging Group
01-SN-05	Day Class
01-SN-06	Evening Class
01-SN-07	Monitor Class
01-SN-08	Warning Tone
01-SN-09	Drop Call – Outgoing
01-SN-10	Drop Call – Incoming
01-SN-11	Intrusion Active
01-SN-12	Intrusion Accept
01-SN-13	Intrusion Tone
01-SN-14	OHVA Active (<i>Reserved</i>)
01-SN-15	OHVA Accept (<i>Reserved</i>)
01-SN-16	Feature Button
01-SN-17	Paging Allow
01-SN-18	ECF Operation
01-SN-19	SMDR Output
01-SN-20	Record Allow
01-SN-21	Port Type
01-SN-22	Directory Number Swapping
01-SN-23-	Line Assignment
01-SN-23-(LN: 01~57)	Line Assignment of Extension ‘SN’ for Line ‘LN’
01-SN-24-	Receive Assignment
01-SN-24-(LN: 01~57)	Receive Assignment of Extension ‘SN’ for Line ‘LN’

Index Prompt	Programming Item
01-SN-25	DSS Unit 1
01-SN-26	DSS Unit 2
01-SN-27	DSS Unit 3
01-SN-28	DSS Unit 4
01-SN-29	Predefined Wrong Destination
01-SN-30	Predefined Busy Forward Destination
01-SN-31	Predefined No Answer Forward Destination
01-SN-32	BOSS 1ST
01-SN-33	BOSS 2ND

Index Prompt	Programming Item
02-	2. CO Line
02-(CO: 740~755)-	Show CO Line:
02-CO-01	Position
02-CO-02	Tenant Group
02-CO-03	Route
02-CO-04	Day Class
02-CO-05	Night Class
02-CO-06	MOH(Music On Hold) Source
02-CO-07	Dialing
02-CO-08	Trunk Type
02-CO-09	Call Abandon
02-CO-10	Private To
02-CO-11	Trunk Ring Type
02-CO-12	Privacy Release
02-CO-13	Busy To Idle
02-CO-14-	Answer Position
02-CO-14-01-(01~06)	Day (Member 1~6)
02-CO-14-02	Night
02-CO-14-03	Predefined No Answer Forward

Index Prompt	Programming Item
03-	3. Call Handling
03-01	Trunk Conference
03-02	CO Flash
03-03	PBX Flash
03-04	Pause Time
03-05-	Dialing Ration
03-05-01	Break Time
03-05-02	Inter-digit Time
03-05-03	Tone Time
03-06	PR Time
03-07	Ring Abandon
03-08	Hold Reminder
03-09	Exclusive Hold Time
03-10-	Warning Time
03-10-01	Outgoing Call
03-10-02	Incoming Call
03-11	XFR Idle Transfer Recall
03-12	XFR Busy Transfer Recall
03-13	SLT Hold Recall
03-14	EKT Hold Recall
03-15-	SLT Hook Flash
03-15-01	Start
03-15-02	End
03-16	PBX Auto Pause
03-17	Dial Wait Time
03-18	Dial Delay
03-19	Camp On Time
03-20	Alarm Play
03-21	Hotel Enable
03-22	System SPD Check
03-23	TSI Connect
03-24	Conference Tone

Index Prompt	Programming Item
03-25	Call Duration Time
03-26	International Prefix Code
03-27	Country Code
03-28	Long Distance Prefix Code
03-29-	Local Area Code
03-29-(01~15 odd no.)	Area Code
03-29-(02~16 even no.)	Area Prefix
03-30-	Tenant Calling
03-30-(TG:1~3)-	Show Tenant:
03-30-TG-01	To Tenant 1
03-30-TG-02	To Tenant 2
03-30-TG-03	To Tenant 3
03-31-	SMDR Call Output
03-31-01	Outgoing Call
03-31-02	Incoming Call
03-31-03	Account Code
03-32-	Automatic Redial
03-32-01	Attempts
03-32-02	Interval
03-32-03	Waiting Time
03-33-	External Call Forward
03-33-01	Service
03-33-02	Talk Time
03-34-	Voice Mail Dialing Ratio
03-34-01	Tone Time
03-34-02	Inter-digit Time
03-35	Voice Mail Monitor Time
03-36	Voice Mail Reserve Port
03-37	FAX Ring Time
03-38	Meet Me Conference Talk Time
03-39	Unsupervised Conference Talk Time
03-40	Predefined Forward Time
03-41	Ring Recognition Time

Index Prompt	Programming Item
03-42	Talk Abandon Time
03-43	Hold Abandon Time
03-44	SLT HF TO HOLD
03-45	CID RPT MOD
03-46	DTMF CID
03-47	CID Delay Time
03-48-	Auto Attendant
03-48-01	Ring Time to Answer
03-48-02	Ring No Answer Time
03-48-03	Drop No Ext DIR.
03-48-04	Transfer Mode
03-48-05	Waiting Code
03-48-06	Inquiry Code
03-48-07	DISA Code
03-48-08-	Answer Position
03-48-08-(TG: 1~3)-	Show Tenant
03-48-08-TG-01	Day Mode
03-48-08-TG-02	Noon Mode
03-48-08-TG-03	Evening Mode
03-48-09-	Show Trunk
03-48-09-CO-01	Auto Attendant Line
03-48-09-CO-02	Service
03-49-	DISA
03-49-01	Ring Time to Answer
03-49-02-(01~08)	Allowed Extension COS
03-49-03-	Show Trunk
03-49-03-CO-01	DISA Trunk
03-49-03-CO-02	DISA Day COS
03-49-03-CO-03	DISA Night COS
03-49-03-CO-04	Service
03-49-03-CO-05	Talk Time

Index Prompt	Programming Item
04-	4. Resource
04-01	Database Password
04-02-	Attendant
04-02-(TG: 1~3)-	Show Tenant:
04-02-TG-01	Primary Attendant
04-02-TG-02	Attendant DSS 1
04-02-TG-03	Attendant DSS 2
04-02-TG-04	Attendant DSS 3
04-02-TG-05	Attendant DSS 4
04-02-TG-06	Alternate Attendant
04-02-TG-07	Alt. Attendant DSS 1
04-02-TG-08	Alt. Attendant DSS 2
04-02-TG-09	Alt. Attendant DSS 3
04-02-TG-10	Alt. Attendant DSS 4
04-03-	System Reminder
04-03-(TG:1~3)-	Show Tenant:
04-03-TG-01	Play Time
04-03-TG-02	Reminder 1
04-03-TG-03	Reminder 2
04-03-TG-04	Reminder 3
04-03-TG-05	Reminder 4
04-03-TG-06	Reminder 5
04-03-TG-07	Reminder 6
04-03-TG-08	Reminder 7
04-03-TG-09	Reminder 8
04-04-	User Password
04-04-01	Length
04-04-02-	Show Extension:
04-04-02-(SN: 101~164)	Password of Extension 'SN'
04-05-	User Name
04-05-(SN:101~164)	User Name of Extension 'SN'
04-06-	Trunk Name

Index Prompt	Programming Item
04-06-(CO: 740~755)	CO Line Name of CO Line 'CO'
04-07-	Preprogrammed Message
04-07-01-	Outgoing Message
04-07-01-(01~06)	Preprogrammed Outgoing Message (01~06)
04-07-02-	Premises Message
04-07-02-(01~06)	Preprogrammed Premises Message (01~06)
04-08-	SPD. Number Assignment
04-08-01-	Individual
04-08-01-(SN:101~164)	Show Extension:
04-08-01-SN-01	To Increase
04-08-01-SN-02	To Decrease
04-08-02-	System List
04-08-02-(TG:1~3)-	Show Tenant:
04-08-02-TG-01	To Increase
04-08-02-TG-02	To Decrease
04-09-	System SPD Number Programming
04-09-(TG:1~3)-	Show Tenant:
04-09-TG-(600~699)	Speed Dial Directory Number:
04-10-	ICLID Name Assignment (<i>Reserved</i>)
04-10-(TG:1~3)-	Show Tenant:
04-10-TG-01	To Increase
04-10-TG-02	To Decrease
04-11-	ICLID Name Programming (<i>Reserved</i>)
04-11-(TG:1~3)-	Show Tenant:
04-11-TG-(EN: 001~100)-	Entry Number:
04-11-TG-EN-01	Name
04-11-TG-EN-02	Phone Number
04-12-	External Pager
04-12-1-	Pager ID: (1)
04-12-1-01	Tenant Group
04-12-1-(02~09)	Paging Group 1- 8
04-13-	Loud Bell
04-13-1-	Loud Bell ID: (1)

Index Prompt	Programming Item
04-13-1-01	Application
04-13-1-(02~09)	Trunk Route 1- 8
04-14-	DSS Allocation
04-14-(DN: 01~12)-	DSS Unit Number:
04-14-DN-01	DSS Owner of DSS Unit 'DN'
04-14-DN-02	DSS Directory Number of DSS Unit 'DN'
04-15-	Built - In MODEM
04-15-01	Directory Number
04-15-02	Baud Rate
04-16	RMT Transmission Rate
04-17	CIL Transmission Rate
04-18	KSU Revision

Index Prompt	Programming Item
05-	5. Restriction
05-01-	Toll Restriction
05-01-(TG:1~3)-	Show Tenant:
05-01-TG- (DI:001~100)-	Digit Interval
05-01-TG-DI-01	From
05-01-TG-DI-02	To
05-01-TG-DI-03	Extension COS
05-01-TG-DI-04	Trunk COS
05-02-	Account Code
05-02-01	Length
05-02-02-	Password
05-02-02-(ID:001~600)-	ID Number
05-02-02-ID-01	PSWD
05-02-02-ID-02	COS
05-02-02-ID-03	Disabled

Index Prompt	Programming Item
06-	6. Extension Application
06-01-	UCD Programming
06-01-(UG:01~24)-	UCD Group:
06-01-UG-01	Tenant
06-01-UG-02	UCD Attribute
06-01-UG-03-	UCD Group Member
06-01-UG-03-(01~24)	Member 1-24
06-01-UG-04	Hunt Method
06-01-UG-05	No Answer Timer
06-01-UG-06	Overflow 1 Timer
06-01-UG-07	Overflow 1 Destination
06-01-UG-08	Overflow 2 Timer
06-01-UG-09	Overflow 2 Destination
06-01-UG-10	Overflow Count
06-01-UG-11	Re-Route Destination
06-02-	Voice Mail
06-02-(TG:1~3)-	Tenant Group:
06-02-TG-01	VM Hunt Group
06-02-TG-02-	Prefix Table
06-02-TG-02-01	ICM/VM
06-02-TG-02-02	Transfer
06-02-TG-02-03	Busy Forward
06-02-TG-02-04	No Answer Forward
06-02-TG-02-05	Direct Forward
06-02-TG-02-06	CO Greeting
06-02-TG-02-07	CO Recall
06-02-TG-02-08	UCD Overflow
06-02-TG-03	Suffix Digit
06-02-TG-04	Record Digit
06-02-TG-05	Delete Digit
06-02-TG-06	Disconnect Digit
06-03-	Auto Record Member

Index Prompt	Programming Item
06-03-(01~08)	Member 1~8
06-04-	Door Phone
06-04-01-	Ring Position
06-04-01-01-	Door Phone Port No.(1-2).
06-04-01-01-(01-04)	Day, Night, Unlock Code, Lock Open_T

Index Prompt	Programming Item
07-	7. CO Line Application
07-01-	Trunk Route
07-01-(CG:01~08)-	Enter Trunk Route:
07-01-CG-01	PBX Code
07-01-CG-02	Hunt Method
07-01-CG-03-	Alternate Trunk Route
07-01-CG-03-(AC: 1~2)	Enter Alternate Trunk Route (1/2)
07-01-CG-03- AC-01	Trunk Route NUMBER(0-8)
07-01-CG-03- AC-02	Delete Digits(0-16)
07-01-CG-03- AC-03	Inserted Digits
07-01-CG-04	Trunk Route Directory Swapping
07-02-	Fax Detection
07-02-01	Trunk Route 705
07-02-02	Trunk Route 711
07-02-03	Trunk Route 717
07-02-04	Trunk Route 723

Index Prompt	Programming Item
08-	8. System Application
08-01	Ring Scheme
08-02	Letter Type
08-03	Hour Mode
08-04	Auto Log-Off
08-05	Log-On Again
08-06	Test Time
08-07-	Position to Directory Number
08-07-(CA: 1/2)	Show Cabinet (1/2)
08-07-CA-(BD:1~4)	Show Board (1~4)
08-08-	Directory Number to Position
08-08-(SN: 101~164)	Enter Directory Number
08-09-	Numbering Plan
08-09-01-	Trunk Route
08-09-01-(01~05)	Length (1~5)
08-09-01-(06~10)	Leading (1~5)
08-09-02-	Extension Directory Number
08-09-02-01	Length
08-09-02-(02~09)	Leading (1~8)
08-09-03-	Extension Paging Group
08-09-03-01	Length
08-09-03-(02~04)	Leading (1~3)
08-09-04-	Extension Hunt Group
08-09-04-01	Length
08-09-04-(02~04)	Leading (1~3)
08-09-05-	Extension Pickup Group
08-09-05-01	Length
08-09-05-(02~04)	Leading (1~3)
08-09-06-	Individual SPD. Number
08-09-06-01	Length
08-09-06-(02~04)	Leading (1~3)
08-09-07-	System SPD. Number

Index Prompt	Programming Item
08-09-07-01	Length
08-09-07-(02~04)	Leading (1~3)
08-09-08-	Trunk Directory Number
08-09-08-01	Length
08-09-08-(02~04)	Leading (1~3)
08-09-09-	Music Source
08-09-09-01	Length
08-09-09-(02~04)	Leading (1~3)
08-09-10-	Loud Bell
08-09-10-01	Length
08-09-10-(02~04)	Leading (1~3)
08-09-11-	External Pager
08-09-11-01	Length
08-09-11-(02~04)	Leading (1~3)
08-09-12-	Virtual Number
08-09-12-01	Length
08-09-12-(02~04)	Leading (1~3)
08-09-13-	Conference Rooms (Meet Me Conference)
08-09-13-01	Length
08-09-13-(02~04)	Leading (1~3)
08-09-14-	Operator Code
08-09-14-01	Length
08-09-14-02	Leading
08-09-15-	Account Code
08-09-15-01	Length
08-09-15-02	Leading
08-10-	Suffix Code
08-10-01	ICM Ring /Voice Interchange
08-10-02	DND Override
08-10-03	Camp On
08-10-04	Callback
08-10-05	Call Pickup
08-10-06	Intrusion

Index Prompt	Programming Item
08-10-07	MSG Waiting
08-10-08	ICM OHVA
08-10-09	Monitor
08-11-	Trunk Copy
08-11-01	Individual Copy
08-11-02	Group Copy
08-12-	Extension Copy
08-12-01	Individual Copy
08-12-02	Group Copy
08-13-	Feature Key Copy
08-13-01	Individual Copy
08-13-02	Group Copy
08-14-	System Time
08-14-01	Year
08-14-02	Month
08-14-03	Day
08-14-04	Weekday
08-14-05	Hour
08-14-06	Minute
08-15-	Time Switching
08-15-(TG: 1~3)	Show Tenant:
08-15-TG-01	Follow Tenant 1
08-15-TG-(WK:02~08)-	Sunday ~ Saturday
08-15-TG-WK-01	Noone Start
08-15-TG-WK-02	Noon End
08-15-TG-WK-03	Evening Start
08-15-TG-WK-04	Evening End