



Software Keycode Installation Guide

Software Keycode Installation Guide

This guide provides instructions for enabling Software Keycodes. Predefined bundles of keycodes may be ordered as a single part although individual keycodes must be entered to enable specific features.

The installer is responsible for obtaining and enabling Software Keycodes. Only registered users can access the Keycode Retrieval System.

Click the Register banner to apply for registration.

Determining the system identification number

You need the system identification number for your system, before you can obtain a Software Keycode:

- Determining the CallPilot 150 system identification number
- Determining the Business Communications Manager system identification number

Determining the CallPilot 150 system identification number

- 1 Log on to CallPilot Manager.
For information about how to log on to CallPilot Manager, refer to the *CallPilot Manager Set Up and Operation Guide*.
- 2 Click the **Installed Options** link.
The system identification number appears in the Serial Number box.
- 3 Record the system identification number in the “Software Keycode Upgrade Information Sheet” on page 6.

Determining the Business Communications Manager system identification number

- 1 Log on to Unified Manager.
For information about how to log on to Unified Manager, refer to the *Business Communications Manager Programming Operations Guide*.
- 2 Click the **System** key and then click the **Licensing** heading.
The system identification number appears in the System Identifier box.
- 3 Record the system identification number in the “Software Keycode Upgrade Information Sheet” on page 6.

Obtaining Software Keycodes

- 1 Access the Nortel Networks Keycode Retrieval System at <http://www.nortelnetworks.com/servsup/krs/>.
- 2 Select the Login Type option that applies to you.
- 3 Select the Product Family option that applies to you.
- 4 Enter your username and password and click the **OK** button.
- 5 Select the Keycode Retrieval System option that applies to you.
- 6 Enter the system identification number from your system.
- 7 Enter the authorization number from the Feature Pack for the specific feature. Use the authorization number you recorded in the “Software Keycode Upgrade Information Sheet” on page 6.
- 8 Click **Validate** to confirm the authorization number.
- 9 Click **Generate** to retrieve the keycode.
- 10 The Software Keycode number consists of three eight-digit numbers. Record the Software Keycode by writing down the number, printing the file, or copying and pasting the information into another document. If you are using Business Communications Manager, you can also download the Software Keycodes file to a shared folder on your computer. You can then use this file to copy the Software Keycodes into your Business Communications Manager system.

Entering Software Keycodes

After you obtain the Software Keycodes, enter these codes in your system:

- “Entering the Software Keycodes on a CallPilot 100/150” on page 4
- “Entering the Software Keycodes on a Business Communications Manager” on page 5
- “Entering Software Keycode Files on a Business Communications Manager” on page 5

Entering the Software Keycodes on a CallPilot 100/150

- 1 Log on to CallPilot Manager.
- 2 Click the **Installed Options** link.
- 3 In the **Keycode** boxes, type the Software Keycode.
- 4 Click the **Add** button.
The option you installed appears in the Installed Options list.

If you use CallPilot 100/150 you can enter Software Keycodes using telephone administration. Refer to the *CallPilot 100/150 Telephone Administration Guide*.

Entering the Software Keycodes on a Business Communications Manager

- 1 Log on to Unified Manager.
- 2 Click the **System** key and then click the **Licensing** key.
- 3 On the **Configuration** menu, click **Add a Keycode**.
- 4 In the **Keycode** box, enter the 24 digit Software Keycode number.
NOTE: Make sure you enter a hyphen between each eight digit segment.
- 5 Click the **Save** button.
After the Software Keycode is accepted and enabled, a confirmation message appears.
- 6 Click the **OK** button.

Entering Software Keycode Files on a Business Communications Manager

If you have a Business Communications Manager system, you can load Software Keycodes by loading the Software Keycode file into your system.

- 1 Log on to Unified Manager.
- 2 Click the **System** key and then click the **Licensing** key.
- 3 Click **Keycode Files** heading.
The Keycode File Location Information window appears.
- 4 In the **Keycode File Location Information** window, enter the information required to access the computer and folder where the Software Keycode file downloaded from the Nortel Networks Keycode Retrieval System is stored.
NOTE: The Software Keycode file must be stored in a shared folder.
- 5 On the **Configuration** menu, click **Apply New Keycode File**.
- 6 Click the **Yes** button.
After the Keycode File is accepted, a confirmation message appears.
- 7 Click the **OK** button.

Software Keycode Upgrade Information Sheet

Authorization
Number

Business Communications
Manager System ID Number

NOTE: Business Communications Manager Software Upgrade

If this keycode is being used for a Business Communications Manager Software Upgrade, enter the keycode number when you are requested to during the Software Upgrade process.

Feature name

Keycode number _____ -- _____ -- _____

Feature name

Keycode number _____ -- _____ -- _____

Feature name

Keycode number _____ -- _____ -- _____

Feature name

Keycode number _____ -- _____ -- _____

Feature name

Keycode number _____ -- _____ -- _____

Feature name

Keycode number _____ -- _____ -- _____